



- 1: Wood Stud Frame
- 2: ArmorWall Plus Structural Insulated Sheathing (R10, R15, or R21 Standard)
- 3: #14-13 Self Tapping Screw
- 4: ArmorSeal Sealant (Gunnable Grade) at all Seams and Fasteners
- 5: Delta Dry and Lath Attached with #10-9 Gimlet Point Self Tapping Screw
- 6: Hard Stucco Scratch Coat
- 7: Hard Stucco Brown Coat
- 8: Hard Stucco Finish Coat



1-844-MAX4YOU
(1-844-629-4968)
www.maxlifeindustries.com

Mail To:
MaxLife Industries
P.O. Box 2128
Salisbury, NC 28145

MAXLIFE
INDUSTRIES
INNOVATING THE
BUILDING ENCLOSURE

Ship To:
4995 South Main Street
Salisbury, North Carolina 28147

DETAIL TITLE:
HARD COAT STUCCO ON ARMORWALL PLUS TO WOOD
STUD WALL FIELD OF WALL

DETAIL NO.:

SCALE:
NTS

REVISION:
01

NOTES:
- ALWAYS FOLLOW STUCCO MANUFACTURER INSTALLATION GUIDELINES.